



Safety glasses should be worn at all times while installing this product.

YEARS: 2018-PRESENT

MAKE: JEEP

MODEL: WRANGLER/GLADIATOR

STYLE: SUV

**WARNING: NEVER EXCEED YOUR VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY**  
 For more information log onto [www.curtmfg.com](http://www.curtmfg.com) & for helpful towing tips log onto [www.hitchinfo.com](http://www.hitchinfo.com)

**WEIGHT CARRYING:**  
 TRAILER WEIGHT: 3,500 LBS.  
 TONGUE WEIGHT: 350 LBS.

**GROSS LOAD CAPACITY WHEN USED AS A STRAIGHT LINE PULL:**  
 9,000 LBS MAX.

**PRO INSTALL TIME: 45 MIN.**  
**NOVICE INSTALL TIME: 90 MIN.**

IF YOU ARE HESITANT TO UNDERTAKE THIS TASK ON YOUR OWN, CONTACT AN AUTHORIZED CURT INSTALLER FOR ADDITIONAL ASSISTANCE.

**INSTALLATION REQUIRES:**

<b>RATCHET</b>	<b>SOCKET</b>	<b>TORQUE WRENCH</b>
<b>TAPE MEASURE</b>	<b>AVIATION SHEARS</b>	<b>MASKING TAPE</b>
<b>SAFETY GLASSES</b>	<b>SCREW DRIVER</b>	

**INSTALLATION TIPS:**

- BEFORE YOU BEGIN INSTALLATION, READ ALL INSTRUCTIONS THOROUGHLY.
- TO EASE INSTALLATION, 2 PEOPLE MAY BE REQUIRED.
- USING PROPER TOOLS WILL GREATLY IMPROVE THE QUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED.
- NEED HELP OR HAVE SOME QUESTIONS? CALL TECHNICAL SUPPORT AT 877.287.8634

**LEVEL OF DIFFICULTY: EASY**


EASY	MODERATE	CHALLENGING
	NO DRILLING REQUIRED	
	REMOVE LOWER FASCIA REMOVE AND RETURN SHIELD	
	TRIM LOWER PLASTIC FASCIA PANEL	
	FISHWIRE	
	WELDNUT CLEANING	

**VEHICLE PHOTO:**



REPRESENTATIVE PHOTO

**HITCH ILLUSTRATION:**



MAKE SURE YOUR HITCH MATCHES




SCAN FOR MORE INFO


**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE ALL FASTENERS ARE TIGHT AND ALL STRUCTURAL COMPONENTS ARE SOUND**  
 CURT Manufacturing LLC. warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, CURT Manufacturing LLC. may repair or replace the product at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. CURT Manufacturing LLC.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.  
 For more information log onto [www.curtmfg.com](http://www.curtmfg.com)  
 This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C.Regulation V-5 and SAE J684.

## INSTALLATION WALKTHROUGH:


Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	10-10281	BOLT,CAR,7/16-14 UNC,1-1/4,GRD8,YZ
2	2	10-10498	HHCS,M10x1.5,35,CL10.9,YZ
3	4	20-00103	NUT,SER-FLANGE,7/16-14 UNC,GRD8,YZ
4	2	30-00163	WASHER,S-CON,7/16,YZ
5	4	30-00210	WASHER,FLAT,3/8,YZ
6	4	CM-SP7	.250 x 1.00 x 2.00" SQUARE HOLE SPACER
7	2	7_16 FISHWIRE	7/16" FISHWIRE
8	1	31086-DSFT	DRIVER SIDE FACIA TAB
9	1	31086-PSFT	PASSENGER SIDE FACIA TAB




CENTER OF PANEL  
**PANEL TRIM DIAGRAM**



- 1) Remove 8 plastic push fasteners from the upper edge of the lower front fascia. Using an 8mm socket, remove the (2) 5mm screws holding the lower edge of the plastic fascia. Using a 16mm socket, remove the (2) 10mm bolts holding the steel shield. Return bolts and shield to vehicle owner, but keep the (2) clip nuts for later reinstallation.



- 2) Raise hitch into position. Loosely install (4) 7/16" carriage bolts and spacers into the remaining mounting holes as shown above by inserting through the closest access hole. Use fishwire for the (2) rearmost bolts. If needed, add (1) or (2) 3/8" washers to each side between the rail and hitch to level the hitch. Install the supplied fascia tabs, (2) 10mm bolts and (2) conical washers thru the hole in hitch and 3/8" washer(s), if applicable, as shown above.




## INSTALLATION WALKTHROUGH:

- 3) Loosely install the supplied 7/16" hex flanges nuts. Torque the 10mm fasteners to 45 lb.-ft. and all 7/16" fasteners to 59 lb.-ft.

**Note:** The small holes in the fascia tabs should be about 31.25" apart to line up with the fascia panel mounting holes.



- 4) Trim the lower plastic fascia as shown in the Panel Trim Diagram to reinstall around the receiver tube of the hitch. Reinstall lower plastic fascia with original fasteners.



# JEEP WRANGLER

**\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY \*\*\*.**

## FRONT MOUNTED ACCESSORIES

1) Do not exceed front axle Gross Weight Rating (GAWR). Consult owners manual or specification plate located on driver's door frame. Measure gross front axle weight by placing front wheels of loaded vehicle on a scale.

**WARNING:** Exceeding GAWR may overload the front axle and/or suspension. This could result in **accident, property damage and personal injury.**

2) Reposition front mounted license plate if obstructed.

3) Do not obstruct vehicle lights.

4) Allow free air flow into grille opening.

5) Rear wheel traction may be reduced. This could effect handling. Reduce speed and drive with caution.

6) Accessories extend front of vehicle. This may reduce approach angle. Use caution when parking and maneuvering.

7) Do not obstruct driver view.

## VEHICLE RECOVERY AND WINCHING TIPS


1) Use OEM tow hooks, recovery eyes or a clevis mount for attachment of a tow strap or winch cable.

**WARNING:** NEVER use a ball and/or ball mount as an anchor point for tow strap or winch cable. Severe personal injury or death could result.

2) Observe winch manufacturer's recommendations, cautions and warnings.

3) Attach return cable to tow hook or recovery eye when using a snatch block (See figure 1).

**CAUTION:** Do not attach return cable to winch mount. This may overload winch mount and/or front mounted receiver.





## RATING

For **Maximum** line pull rating, winch cable must not exceed:

- 15 degree angle up or down from horizontal (See Figure 2).
- 45 degree angle left or right from straight ahead (See Figure 3).

**CAUTION:** Exceeding the maximum line pull rating may over load winch, winch mount, and/or front mounted receiver.



31086

## JEEP WRANGLER/GLADIATOR

08/13/2020

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3,500 LBS. TRAILER WEIGHT &amp; 350 LBS. TONGUE WEIGHT.

GROSS LOAD CAPACITY WHEN USED AS A STRAIGHT LINE PULL: 9,000 LBS. MAX. LINE PULL.


**WARNING: \*\*\* DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. \*\*\***FOR MORE INFORMATION LOG ONTO WWW.CURTMFG.COM  
HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-877-287-8634

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	10-10281	BOLT,CAR,7/16-14 UNC,1-1/4,GRD8,YZ
2	2	10-10498	HHCS,M10x1.5,35,CL10.9,YZ
3	4	20-00103	NUT,SER-FLANGE,7/16-14 UNC,GRD8,YZ
4	2	30-00163	WASHER,S-CON,7/16,YZ
5	4	30-00210	WASHER,FLAT,3/8,YZ
6	4	CM-SP7	.250 x 1.00 x 2.00" SQUARE HOLE SPACER
7	2	7_16 FISHWIRE	7/16" FISHWIRE
8	1	31086-DSFT	DRIVER SIDE FACIA TAB
9	1	31086-PSFT	PASSENGER SIDE FACIA TAB

## FISHWIRE TECHNIQUE

INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND OUT THE ACCESS HOLE. PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEEP SPACER SEPARATE FROM BOLT AS SHOWN. PULL FISHWIRE, SPACER, AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT / SPACER INSIDE FRAME RAIL.

\*\*NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME\*\*

CENTER OF PANEL  
PANEL TRIM DIAGRAM

TOOLS REQUIRED
RATCHET
TORQUE WRENCH
SAFETY GLASSES
STRAIGHT SCREW DRIVER
AVIATOR SHEARS
8mm, 16mm, 17mm SOCKETS
11/16" SOCKET
TAPE MEASURE
MASKING TAPE

HITCH WEIGHT: 16 LBS.


## INSTALL TIME

PROFESSIONAL: 45 MINUTES

NOVICE (DIY): 90 MINUTES

## INSTALL NOTES:

- REMOVE SKID SHIELD
- REMOVE LOWER FASCIA PANEL
- NO DRILLING REQUIRED
- TRIM LOWER FASCIA PANEL



## WELDNUT CLEANING

To remove debris from weldnuts in frame, spray lubricant or compressed air into hole. For heavy debris, use a small wire brush. (Be careful not to damage threads).

## INSTALLATION STEPS

- 1) Remove (8) plastic push fasteners from the upper edge of the lower front fascia. Using an 8mm socket, remove the (2) 5mm screws holding the lower edge of the plastic fascia. Using a 16mm socket, remove the (2) 10mm bolts holding the steel shield. Return bolts and shield to vehicle owner, but keep the (2) clip nuts for later reinstallation.
- 2) Raise hitch into position. Loosely install (4) 7/16" carriage bolts and spacers into the remaining mounting holes as shown above by inserting through the closest access hole. Use fishwire for the (2) rearmost bolts. If needed, add (1) or (2) 3/8" washers to each side between the rail and hitch to level the hitch. Install the supplied fascia tabs, (2) 10mm bolts and (2) conical washers thru the hole in hitch and 3/8" washer(s), if applicable, as shown above.
- 3) Loosely install the supplied 7/16" hex flanges nuts. Torque the 10mm fasteners to 45 lb.-ft. and all 7/16" fasteners to 59 lb.-ft.  
**Note:** The small holes in the fascia tabs should be about 31.25" apart to line up with the fascia panel mounting holes.
- 4) Trim the lower plastic fascia as shown in the Panel Trim Diagram to reinstall around the receiver tube of the hitch. Reinstall lower plastic fascia with original fasteners.

**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**



Scan for more information

CURT Manufacturing LLC., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, CURT Manufacturing LLC., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. CURT Manufacturing LLC.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.

This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C.Regulation V-5 and SAE J684.

# JEEP WRANGLER

**\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY\*\*\*.**

## FRONT MOUNTED ACCESSORIES

1) Do not exceed front axle Gross Weight Rating (GAWR). Consult owners manual or specification plate located on driver's door frame. Measure gross front axle weight by placing front wheels of loaded vehicle on a scale.

**WARNING:** Exceeding GAWR may overload the front axle and/or suspension. This could result in **accident, property damage and personal injury.**

- 2) Reposition front mounted license plate if obstructed.
- 3) Do not obstruct vehicle lights.
- 4) Allow free air flow into grille opening.
- 5) Rear wheel traction may be reduced. This could effect handling. Reduce speed and drive with caution.
- 6) Accessories extend front of vehicle. This may reduce approach angle. Use caution when parking and maneuvering.
- 7) Do not obstruct driver view.


## VEHICLE RECOVERY AND WINCHING TIPS

1) Use OEM tow hooks, recovery eyes or a clevis mount for attachment of a tow strap or winch cable.

**WARNING: NEVER** use a ball and/or ball mount as an anchor point for tow strap or winch cable. Severe personal injury or death could result.

- 2) Observe winch manufacturer's recommendations, cautions and warnings.
- 3) Attach return cable to tow hook or recovery eye when using a snatch block (See figure 1).

**CAUTION:** Do not attach return cable to winch mount. This may overload winch mount and/or front mounted receiver.



## RATING

For **Maximum** line pull rating, winch cable must not exceed:

- 15 degree angle up or down from horizontal (See Figure 2).
- 45 degree angle left or right from straight ahead (See Figure 3).

**CAUTION:** Exceeding the maximum line pull rating may over load winch, winch mount, and/or front mounted receiver.

